


STAIR TREAD & RISER INSTALLATION



TZ303 SLIP RESISTANT STAIR TREADS AND STAIR RISERS



- 1 Cut Terrazzo Stair Tread & Riser to proper depth and length.
- 2 Install Terrazzo Riser flush with the Terrazzo Stair Tread surface.
- 3 Apply thin-set mortar (e.g. LATICRETE 254 Platinum) along edge area above the riser.
- 4 Fill the cavity on the underside of the Terrazzo Stainless Steel Stair Nosing profile with thin-set mortar.
- 5 Press Terrazzo Stainless Steel Stair Nosing completely into the thin-set mortar and align, making sure that the front edge of the Terrazzo Stainless Steel Stair Nosing profile overlaps the riser tile.
- 6 Completely cover the Terrazzo Stainless Steel Stair Nosing perforated anchoring leg and the Terrazzo Tread area with thin-set mortar.
- 7 Solidly embed the Terrazzo Stair Tread so that the Terrazzo surface is flush with the top of the Terrazzo Stainless Steel Stair Nosing. **Note: the Stainless Steel Stair Nosing should not be higher than the Terrazzo Stair Tread, but rather flush or up to approximately 1/32" (1mm) lower.**
- 8 A joint of approximately 1/16" - 1/8" (1.5 - 3mm) should be left between the Terrazzo Stair Tread and the Stainless Steel profile.
- 9 Fill the joint completely with grout. (e.g. LATICRETE Perma Color Grout.) **When Terrazzo Stainless Steel Stair Nosing is integrated into screed layers, the profile must be completely embedded in the mortar. The trapezoid-perforated anchoring leg must be covered with at least 9/16" (15mm) of mortar.**
- 10 When using surface coatings, Terrazzo Stainless Steel Stair Nosing is adhered to the edge of the Terrazzo Stair Tread and adjusted in such a way that the front edge of the profile is flush with the riser. The trapezoid-perforated anchoring leg is covered completely with the surface coating, so that the finished surface is just flush with the profile.